

# Elmasonic Select

Quick Start Guide.



# Elmasonic Select

1

Diagram showing the unboxing of the Elmasonic Select machine. An open cardboard box is shown next to the machine. A QR code and an information icon (i) are also present. The machine is shown with its lid open, revealing the internal components. The machine is labeled '500 / 900' and '30 - 300'. A power cord and a manual are also shown.

Diagram showing the assembly of the lid. The lid is shown being attached to the machine. The lid is labeled '500 / 900'. The machine is labeled '30 - 300'. The lid is shown being attached to the machine. The lid is labeled '500 / 900'. The machine is labeled '30 - 300'.

2

Diagram showing the power connection. The machine is shown with its lid open. A power cord is shown being plugged into the machine. The machine is labeled '500 / 900' and '30 - 300'.

3

Diagram showing the water filling process. Water is shown being added to the machine. The machine is labeled '500 / 900' and '30 - 300'.

Diagram showing the cleaning agent instructions. A cleaning agent bottle is shown being added to the machine. The machine is labeled '500 / 900' and '30 - 300'.

4

Diagram showing the loading of the machine. The machine is shown with its lid open. The machine is labeled '500 / 900' and '30 - 300'.

Diagram showing a safety warning. A warning symbol is shown. The machine is labeled '500 / 900' and '30 - 300'.

On / Off


dyn pulse sweep eco degas

+ min / h °C / °F -


Start / Stop

## On / Off

5





6




## On / Off

7




8.1

30 - 40



8.2

60 - 300



8.3

500 / 900

Elma Schmidbauer GmbH  
Gottlieb-Daimler-Straße 17  
78224 Singen (Germany)

[info@elma-ultrasonic.com](mailto:info@elma-ultrasonic.com)  
[www.elma-ultrasonic.com](http://www.elma-ultrasonic.com)



Art. no.: 1148035 Technische und optische Änderungen vorbehalten. 08\_26