

elma clean 85 (EC 85) **NEUTRAL JEWELLERY CLEANING CONCENTRATE** *works very gentle*

Description

For jewellery manufacture and restoration of worn jewellery. Cleans quickly precious metals and gems.

Reliably removes dirt, fat, grease, sweat, cosmetic residues and soap, lapping residues, polishing paste, buffing compound.

- Free of alkalies and acids.
- Biodegradable.
- Without smell.
- Harmless to the skin, an important factor in the jeweller's workshop.

Application and Dosage

With Ultrasonic Cleaning Bath: Dosage: 5% in water. Time: 1 – 5 min.

Temperature: 30°C – 60°C; works also at room temperature, but slower.

Without Ultrasonic Cleaning Bath: Dosage: 10% in water. Time: 10 – 30 min.

Temperature: 50°C – 75°C. Agitate workpieces, moving of pieces recommended.

Restrictions: Do not use ultrasonics with frequencies ≤ 50 kHz for amorphous or soft stones as pearls, corals, lapis etc. Rinse workpieces after immersion with water and dry.

Safety recommendations

elma clean 85 (EC 85) is not classified as hazardous according to Regulation (EC) No 1272/2008 [GHS]. Observe the hints indicated in the Safety Data Sheets. Always handle chemicals with care.

Physical-chemical characterisation

Density: 1070 g/l, pH: ~9. pH: 7 – 7.5 with concentration 1%.

Ingredients according to Annex VII, A, EC-Regulation 648/2004 (detergents): 15-30% anionic surfactants, <5% non-ionic surfactants, 2-Bromo-2-nitropropane-1,3-diol (~35 ppm).

Disposal

The surfactants in our product meet the criteria for biodegradation as laid down in Annex III of the Regulation (EC) No 648/2004 on detergents.

The cleaning bath can be fed into the public sewage system; observe the local pH limit values and make sure that the contamination contained complies with the local sewage regulations.

European waste code: 20 01 30, „detergents other than those mentioned in 20 01 29“.

Volumes, storage and transport

Available volumes: 1 litre PE-bottle; 10 litre and 25 litre HDPE-can; 200 litre barrel.

Store in closed original container at a temperature between +5°C and +30°C, protected from heat and direct solar radiation. Store at a cool place.

Shelf life: 5 years from date of production (see stamp on label).

Classification for all means of transport: no hazardous material.



Elma Schmidbauer GmbH

Gottlieb-Daimler-Str. 17, D-78224 Singen

E-Mail: info@elma-ultrasonic.com

15.05.2019 / (GB) Version 1.5

Tel.: +49 7731 882-0

Fax: +49 7731 882-266

www.elma-ultrasonic.com