

VACU-Proof

SEALING LIQUID FOR STATIC AND DYNAMIC SEALS IN WATERRESISTANT WATCHES OR PRECISION DEVICES

Description

VACU-Proof is a sealing liquid for the re-sealing of sealed surfaces and gaskets or other sealants in waterresistant watches or other precision devices after their opening for services. *VACU-Proof* is suitable for all waterresistant joints (e.g. watch-case, crown-shaft, glass).

Application and dosage

To be dropped on to sealing surfaces and gaskets or other sealants. *Vacu-Proof* is ready for use.

Safety recommendations

VACU-Proof is not classified as hazardous according to Regulation (EC) No 1272/2008 [GHS]. Observe the hints indicated in the Safety Data Sheets. Always handle chemicals with care.

Physical-chemical characterisation

The product is not miscible with water and keeps on top of water.
Density: 0,97 g/ml. Mixture of polydimethylsiloxanes.

Disposal

Recommendations:

1. Disposal regulations same as for used oil.
2. Dispose via specialised disposal companies: European waste code: 13 02 06*, „synthetic engine, gear and lubricating oils“.
3. Burn in suitable equipments, but according to official regulations.

Do not discharge into the drains/surface waters/groundwater. Do not discharge into public sewage system. Do not discharge into the subsoil/soil.

Volumes, storage and transport

Available volumes: 25 ml in a flask with sealable dosage channel.

Store in closed original container. Protect from heat and direct solar radiation.

Shelf life: 5 years from date of production (see stamp on label).

ADR classification for all means of transport: no hazardous material.

