



Elma Schmidbauer GmbH · Postfach 280 · D-78202 Singen

Release Notes – Elmasolvex VA R008

Changes to the Elmasolvex VA Software from version R007 to R008.

New:

1. Improved drying:

It is now possible to set – instead of only slow rotation – the spin speed up to 500 rpm in the step „Drying“ in the cleaning program. (Expert- and Standard Editing Mode)

This leads to a significantly improved drying and an overall shortened total running time of the cleaning programs (compared to software version R007). Now the pre-defined "Standard", "Short" and "Intensive" programs also use the spin cycle at 500 rpm. This also shortens the total run time of these programs.

2. Service Display:

If the 5-year service interval defined in the operating instructions is due, a corresponding notification is now displayed. The reminders are displayed in 4 tiers:

- The first notification 6 months before the end of the 5 years.
- The second notification 4 months before the end of the 5 years.
- The third notification 2 months before the end of the 5 years.
- The last notification after 5 years.

3. Reduced tendency for foam formation due to optimized switching on of the ultrasound and the rotational movement of the basket.

Bug Fixes:

Various minor bug fixes for improved stability.