



Elma Schmidbauer GmbH · Postfach 280 · D-78202 Singen

## Release Notes – Elmasolvex VA R012

Changes to the Elmasolvex VA Software from version R011 to R012.

### Neu:

1. A new softkey is now available on the left side in the settings of the Elmasolvex VA. This softkey starts the new „Automatic media container & machine cleaning“.  
With the help of this cleaning a cleaning chemical is sucked from container 4 into the machine. This is then drained into container 3, sucked back in and drained into container 2. Finally, the chemistry is sucked from container 2 and drained into container 1.
2. There are three new warning messages that have been introduced as part of the new "Automatic media container & machine cleaning". For cleaning, there must be no liquid in the containers in position 1, 2 and 3. This is checked at the beginning of the cleaning process. If liquid is detected, the corresponding warning message appears:
  - Warning 34: Liquid detected in media container 1.
  - Warning 35: Liquid detected in media container 2.
  - Warning 36: Liquid detected in media container 3.
3. The new Elma Logo is now used in the start screen.

### Bug fixes:

Besides minor bug fixes that lead to an optimised stability, the following bugs hves been fixed:

1. A bug was fixed that – under certain circumstances - caused that more than 13 custom programs could be created.
2. A bug was fixed that – under certain circumstances – caused that the „Ok“-button didn't respond when displaying the „Cleaning Complete“ screen.