

Cyclomotion

Watch winder

Elma Order Nos

Cyclomotion (without clips)	103 5171
Cyclomotion pro (without clips)	103 5170
clips for 2 watches with watchstraps 165 - 205 mm	103 5190
clips for 4 watches with watchstraps 165 - 205 mm	103 5192
clips for 2 watches with watchstraps (wind up left/right) 165 - 205 mm	103 5359
clips for 4 watches with watchstraps (wind up left/right) 165 - 205 mm	103 5360
clips for 2 watches with watchstraps 150 - 165 mm	104 5571
clips for 4 watches with watchstraps 150 - 165 mm	104 5573
clips for 2 watches with watchstraps (wind up left/right) 150 - 165 mm	104 5566
clips for 4 watches with watchstraps (wind up left/right) 150 - 165 mm	104 5568
Industrial clip 4	103 5361
Watch box for up to 4 watches	105 3528
Cyclomotion wall bracket	103 5701



Cyclomotion pro mit Protectorhaube

The professional watch winder

The Cyclomotion with a modern design is the perfect further development of the proven Cyclomat for winding mechanical watches. The various possible options for watch mounting enable individual configuration of the watch winder tailored to the respective requirements. Different winding variants guarantee optimum winding and testing according to the respective requirements of the watch movements. In particular, large and heavy mechanical watches can also be wound by the powerful motor. Due to its versatility, the Cyclomotion is designed for watch manufacturers and watchmakers.

Product Features

- powerful, quiet motor with integrated slip clutch and holding torque (in standby mode)
- adjustable speed: 1 rpm or 4 rpm for continuous tests and fast winding of the watches
- adjustable rotation directions: clockwise, anti-clockwise and clockwise / anticlockwise by rotation direction change
- individually selectable retaining bracket combination enables simultaneous winding on one or both sides of watch movements to be wound
- Cyclomotion pro with lockable protection cover provides additional protection against dust and mechanical influence



Cyclomotion

in open design with 6 clamps for winding on both sides



Watch Box

for up to 4 watches without bands with a diameter of max. 40 mm



Industrial Clamp

for up to 4 watches without bands

Technical data

Rotational direction	left / right	Weight Cyclomotion pro (kg)	approx. 16
Rotation radial (rpm)	1 or 4	Clip (kg/pc.)	approx. 0.1
Rotation axial (rpm)	4.5 or 18	Mains voltage (VAC)	100 - 240
Cyclomotion max. W / D / H (mm)	465 / 325 / 520	Mains frequency (Hz)	50 / 60
Cyclomotion pro max. B / T / H (mm)	635 / 325 / 585	Power consumption total (W)	approx. 24
Weight Cyclomotion (kg)	approx. 11	Power consumption total standby (W)	approx. 24